

August[®]

User Manual

DVB-T305



August International Ltd
United Kingdom
Telephone: +44 (0) 845 250 0586
www.augustint.com

EN Freeview HD Receiver

FR Récepteur TNT HD

DE DVB-T Receiver

IT Ricevitore TDT HD

ES Sintonizador TDT HD

User Manual

Thank you for purchasing this August DVB-T305. You may already be familiar with using similar products but please take the time to read these instructions carefully. They are designed to familiarise you with the product's many features and to ensure that you get the very best from your purchase.

Safety

Please read the Safety Instructions before using this product to ensure your safety and the safety of others.

Disposal

Please ensure the product and its accessories are disposed in compliance with WEEE (Waste Electrical and Electronic Equipment) Directive and any other applicable regulations. Please check with your local authority for current disposal regulations.

Declaration of Conformity

The Declaration of Conformity can be found on our website at <http://augustint.com/en/declaration/>

Customer Service



If you need help, please contact our Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com

Quick Start Guide

DVB-T305

1. Open the Play Store on your smartphone or tablet, or scan the QR code below then download the “August 305” App.
2. Connect the DVB-T305 to an antenna. It is suggested that you use a rooftop antenna when searching for TV channels for the first time.
3. Plug the DVB-T305 into the USB socket of your Android tablet or phone. Once connected, confirm “Open August 305 when this device is connected?”
4. On the initial start-up screen tap “Goto” for the Channel Scan screen and select your country from the list and tap “Scan”.
5. When the scan has finished tap  on the app screen to begin watching TV.
6. Tap the screen to bring up the option buttons. Use  to access the channel list.

PLEASE NOTE: The TV signal strength in some areas may not be sufficient to support TV reception using a portable antenna. The distance from the closest transmitter and other factors such as surrounding buildings, the walls of your house, weather and electromagnetic interference caused by power and telecommunication infrastructure may affect signal strength. Changing location may improve signal reception and a rooftop antenna designed for digital TV can be used to achieve the best possible reception.




Contents

1. Safety Instructions	1
2. Main Features	2
3. Accessories	2
4. Part names and Functions	2
5. Installation and Connection	3
6. Unit Operation	3
6.1 TV Channel /Favourite List	4
6.2 EPG (Electronic Program Guide)	4
6.3 Aspect ratio select	4
6.4 Audio Language	4
6.5 Information	5
6.6 Settings	5
6.7 Recordings	5
7. Specifications	6
8. Troubleshooting	6
9. Warranty	7

1. Safety Instructions

■ Storage and Use



■ Maintenance

Please unplug all connection wires before cleaning this machine.




2. Main Features

- TV Receiver for Tablets and Smartphones
- DVB-T and DVB-T2 compliant
- USB Powered Android PVR
- Electronic Program Guide
- Record and play back TV programmes
- Android OS 4.1+ Compatible. USB OTG required
- Supports MPEG2 MP@ML and H.264 / H.265




3. Accessories



4. Part names and Functions



5. Installation and Connection

1. Open the Play Store on your smartphone or tablet and download the “August 305” App.
2. Connect the DVB-T305 to an antenna. It is suggested that you use a rooftop antenna when searching for TV channels for the first time.
3. Plug the DVB-T305 into the USB socket of your Android tablet or phone. Once connected, confirm “Open August 305 when this device is connected?”
4. Tap  to enter the settings menu and Tap  **Channel Scan** to launch a new search.
5. Tap the country selection in the bottom left and select your country, then tap “Scan”. The device will show a progress bar and begin to scan for TV channels. It will take several minutes to scan all frequencies.
6. When the scan has finished tap  on the app screen to begin watching TV

6. Unit Operation



In Live TV view, tap the TV program screen to bring up the options:



- | | |
|-----------------------------------|---|
| 1. TV Channel / Favourite List | 5. Channel information bar (Now / Next program, Battery, signal, Recording on/off and time) |
| 2. EPG (Electronic Program Guide) | 6. Settings |
| 3. Aspect ratio select | 7. Recording |
| 4. Sound options | |

Note: When watching TV you can swipe up / down to adjust the volume, and left / right to select between previous and next TV channels.

6.1 TV Channel/Favourite List

Tap  to access the TV Channel List. Tap the channel to select it and bring up the buttons to add the channel to favourites, or view the EPG for this specific channel. Tapping  adds or removes the channel from the favourites list.

Tapping **EPG** brings up the Electronic Program Guide for the channel.

Tap  to close the menu.

6.2 EPG (Electronic Program Guide)


Tap **EPG** to bring up the Electronic Program Guide for the current channel.

Swipe up/down to view the TV program schedule, and tap a day button to change day.

6.3 Aspect ratio select

Tap the Aspect ratio button to cycle between 4:3 / 16:9 / 16:10 / Full Screen



6.4 Audio Language

Tap  to bring up a list of available languages then select the language required.

6.5 Information


Whilst watching TV, tapping the TV screen will bring up the Channel information bar at the bottom of the screen.


The information bar will show:

- the current channel
- the program information (now playing and next)
- the recording status (on/off) 
- the TV signal strength 
- Your Android device battery level


6.5.1 Record


To record a TV program tap the screen to show the Channel information bar.

Press  to start. An Icon will appear in the top right to show the length of time of the recording.



To stop recording, press  again.

6.6 Settings

Tapping  will enable you to perform a new channel scan, as well as showing information about the app.

Tap  to leave the settings menu.

6.7 Recordings

Tapping  brings up a list of your previous recordings with the option to watch or delete them and the available space for recordings. To play a recording tap . You will then be asked which player the file should be read with.

Note: Recordings are in .ts file format. Not all players can read this format.

To delete a recording tap  and confirm by tapping “OK” or cancel by tapping “Cancel”.

7. Specifications

Receiver	DVB-T/T2, Supports EPG
Receive frequency	48.25 to 863.25 MHz
Bandwidth	1.7/5/6/7/8/10 MHz
Support Devices	Android Phone and Tablet
System Requirement	Android OS 4.1 or higher
Antenna input impedance	75 Ohm
Recording Format	Video: MPEG2 MP & ML / H.264 & 265 Audio: MPEG2 Audio Layer I & II
Dimensions	68mm x 40mm x 17mm
Net Weight	6 g

8. Troubleshooting

Question	Possible causes and solution
No Image	Check the August 305 App has been installed. Confirm the Open August 305 message with “OK”. Try removing and reinserting the DVB-T305.
No Sound	Swipe up to raise the volume or use your tablet or smartphone volume control. Check the connection to the target audio device.
Picture freezing and/or sound distorted	Signal too weak, please check the antenna connection or upgrade to an amplified or rooftop aerial.
No Signal	Signal too weak, please check the antenna connection or upgrade to an amplified or rooftop aerial.
Not Recording	Check available space for recordings and delete if necessary. You may need to remove files from your smartphone or tablet to create space.

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in the case that the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover damage caused by misuse, negligence, accident or natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexperienced repairs. The manufacturer disclaims any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU. The Declaration of conformity may be consulted online at <http://www.augustint.com/en/declaration>.

