August® User Manual

EP610

EN	Bluetooth Headphones
FR	Ecouteurs Bluetooth
DE	Bluetooth Kopfhörer
IT	Auricolari Bluetooth
ES	Auriculares Bluetooth

User Manual

Thank you for purchasing the August EP610 Bluetooth Wireless Headphones. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device.

Please do not disassemble the EP610, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country.

Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

Quick Start Guide

1. Please fully charge the EP610 battery before first use. To charge, connect the USB charging cable from a powered USB socket to the headphone power socket. The status LED will light red whilst charging and change to blue once fully charged.

2. To pair, ensure the EP610 is powered off, then press and hold the "►" button for about 6 seconds until the LED flashes alternately red and blue. Search for available Bluetooth devices on your mobile phone, tablet or computer. The headphones will appear as "EP610". Once paired, the status LED will slowly flash blue to confirm connection.

3. Select the appropriate ear buds and ear clips for a comfortable and secure fit.

4. Playback is controlled by your source device, or via the headphone controls for devices which support A2DP.

5. To switch off the device press and hold the "►" button until the status LED changes to red and the switch off tone is heard.

For any further queries, please telephone August International Ltd helpline +44 (0) 845 250 0586 or email service@augustint.com

1. Safety Instructions

■ Storage and Use

	Keep this device away from extreme temperatures.		Keep the device away from wet or damp environment.
	Never expose to moisture, dust, oil or smoke.		Avoid dropping or exposing to impacts.
	When carrying this device as part of your luggage please ensure it is securely stored to avoid impact damage.		Never strike or scratch this device with any sharp object.

■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.

2. Main Features

- ■ Wireless Headset for Bluetooth Devices
- ■ Integrated Microphone for Hands-free Calls
- ■ Built-in Rechargeable Battery
- ■ Micro USB Charging Port
- ■ Range: up to 10m(Class II)
- ■ Bluetooth Version: 4.0

3. Accessories

1) USB charging cable
2) Ear Buds * 3 pairs
3) Ear Clips * 4 pairs
4) User manual

4. Part Names and Functions

1. Volume Down / Previous Track
2. Power / Play / Pause / Answer
3. Volume Up / Next Track
4. Status LED
5. Microphone

6. Charging Socket

5. Operation

5.1 Switch On / Off

To switch the device on press and hold the "►" button until the status LED flashes blue and a switch on tone sounds.

To switch the device off press and hold the "►" button until the status LED lights red and the switch off tone sounds.

5.2 Bluetooth Connections

To pair with a device, turn the EP610 off, then press and hold the "►" button until the status LED flashes alternately red and blue (approximately 6 seconds).

■ For mobile phones

1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed).
2) Select "EP610" from the available devices and confirm connection.
3) The status LED flashes blue once every 5 seconds whilst paired.
   Note:
   Accessing Bluetooth settings on mobile phones varies for each phone, to find the information for your phone, please refer to its user manual.

■ For computers

1) Enable the Bluetooth function on your computer.
2) Select "Devices and Printers" from the Control Panel

3) Select "EP610" from the available devices, the system will install the driver automatically.
   Note:
   For Windows 98, XP and Vista, a third-party Bluetooth driver is needed (not included).
4) The status LED flashes blue once per second whilst paired.
5) If the EP610 is not automatically set as your output device, select "Sound" from the control panel then highlight the EP610 and select "Set Default".

Note:
When switched on, the EP610 will automatically reconnect to the last paired Bluetooth device if it is in range.

5.3 Remote Control

The EP610 is able to control the music playing on either a mobile phone or a computer with a Bluetooth connection.

Press "►" to pause or resume music playback.
Press "+" or "-"to increase or decrease the volume.
Press and hold "+" or "-" for approximately a second to select the next or previous track.

Note:
The remote control is only compatible with devices that support A2DP, please refer to your devices user manual for its A2DP compatibility.

5.4 Hands-free Calling

Whilst connected to your mobile phone, the EP610 will act as a hands-free system for calls.

Press " ► "to pick up or hang up a call. Press and hold " ► " for 2 seconds to reject the incoming call.

Double press" ► " to redial the last called number.
\

6. Charging

When the battery is low, a warning tone beeps once per minute and the status LED flashes red to indicate low power. To recharge the battery, use the supplied micro USB cable to connect the EP610 to a powered USB port.

The status LED constantly lights red whilst charging and turns blue once the battery is fully charged.

Note:
1) Only use certified USB chargers from branded manufacturers.
2) Fully charge the headset before first use.
3) If unused for a long period of time, fully charge the battery before use.

7. Specifications

Bluetooth Specification	v4.0
Operating Range	Up to 10m
Frequency Response	200Hz to 20KHz
Speaker Output	10mW×2
SNR	≥80dB
Distortion	≤1% At 1KHz
Battery	3.7V/40mAh×2 Built-in Polymer Lithium Battery
Working Time	6 hours
Charging Time	1 hour
Weight	15g
Dimensions	595 x 12.4 x 34.5mm

8. Troubleshooting

Problem	Solution
Won't turn on	Please charge the EP610. Press and hold the power button for 2 seconds.
Can't find the EP610	Confirm the EP610 is in pairing mode and within 10 meters from the device.
Can't install the driver for EP610 on a computer	For Windows 98, XP and Vista computers, a third-party Bluetooth driver is needed (not included) For Windows 7 and 8 computers, please update the driver of the Bluetoothmodule on your computer. For detailed information of your Bluetooth module,please contact the computer supplier.

Problem	Solution
The sound quality is intermittent in Bluetooth mode.	Please ensure the headset is within 10 meters of yoursource device. Disable the Wi-Fi on your source device.
No sound	Check the volume on both the source device and the EP610. If the headset is connected to a computer, please check that the headset is set as the current audio out device
The mobile phone asks for a PIN code	The PIN code for the EP610 is 0000

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.

- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:
Telephone: +44 (0) 845 250 0586
Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at August International Ltd, Unit 5 Swains Mill, Crane Mead, Ware SG12 9PY, England.

$C\epsilon$

Industry Canada Statement
This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.

FC

For details of further relevant technical standards, please contact us at the address above.