

# August<sup>®</sup> User Manual

— EP620 —

EN Bluetooth Headset

FR Oreillette Bluetooth

DE Bluetooth Headset

IT Auricolare Bluetooth

ES Auricular Bluetooth

August International Ltd  
United Kingdom

Telephone: +44 (0) 845 250 0586

[www.augustint.com](http://www.augustint.com)

## User Manual

Thank you for purchasing the August EP620 Bluetooth Wireless Headset. This user manual is designed to familiarise you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

### Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device.

Please do not disassemble the EP620, it can be unsafe and will invalidate the manufacturer's warranty.

### Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country.







Always check with the environment agency and any other relevant authorities for current disposal regulations.

### Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: [service@augustint.com](mailto:service@augustint.com) should you require further technical support or customer service.



## 1. Safety Instructions

### ■ Storage and Use

	Keep this device away from extreme temperatures.		Keep the device away from wet or damp environment.
	Never expose the device to moisture, dust, oil or smoke.		Avoid dropping or exposing to impacts.
	When carrying this device as part of your luggage please ensure it is securely stored to avoid impact damage.		Never strike or scratch this device with any sharp object.

### ■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
---	--	--	--

## 2. Main Features


- Wireless Headset for Bluetooth Devices
- Hands-Free Calls with Integrated Microphone
- Built-in Rechargeable Battery
- Micro USB Charging Port
- Range: up to 10m (Class II)
- Bluetooth Version: 3.0+EDR

## 3. Accessories




- 1) USB charging cable
- 2) User manual

## 4. Part Names and Functions



- 1) Status LED
- 2) Enter
- 3) Volume Up



- 4) Volume Down
- 5) Power Socket
- 6) Microphone

## 5. Operation

### 5.1 Switch On / Off

To switch the device on, press and hold the Enter button until the device says “power on”. Whilst on and unpaired, the status LED flashes blue.

To switch the device off, press and hold the Enter button for 3 seconds, until the device says “power off”. The status LED will flash red then turn off.

### 5.2 Bluetooth Connections

To pair to a device, turn the EP620 off, then press and hold the Enter button for 6 seconds to enter pairing mode. Whilst in pairing mode, the status LED flashes red and blue.

#### ■ For mobile phones

- 1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed).
- 2) Select “EP620” from the available devices and confirm connection.
- 3) The status LED double flashes once per second whilst paired.

#### Note:

Accessing Bluetooth settings on mobile phones varies for each phone, to find the information for your phone, please refer to its user manual.

#### ■ For computers

- 1) Enable the Bluetooth function on your computer.
- 2) Select “Devices and Printers” from the Control Panel and click “Add a Device”.

- 3) Select “EP620” from the available devices, the system will install the driver automatically.

**Note:**

For Windows 98, XP and Vista, a third-party Bluetooth driver is needed (not included).

- 4) The status LED double flashes once per second whilst paired.
- 5) If the EP620 is not automatically set as your output device, select ”Sound” from the control panel then highlight the EP620 and select “Set Default”.

**Note:**

When switched on, the EP620 will automatically reconnect to the last paired Bluetooth device if it is in range.

### 5.3 Voice Control

Press the Enter button to activate your mobile phone’s voice control.

### 5.4 Hands-free Calling

Whilst connected to your mobile phone, the EP620 will act as a hands-free system for calls.

#### 5.4.1 Answering / Ending a call

Press the Enter button to answer the incoming call or end the current call.

#### 5.4.2 Rejecting an incoming call

Press and hold the Enter button for 3 seconds to reject the incoming call.

#### 5.4.3 Handset Transfer

During a call, press and hold the Volume up

button for 3 seconds to transfer the In-Call audio source between the phone and the headset.

#### 5.4.4 Call waiting

If you receive a call whilst a call is in progress, press the Enter button to end the current call and answer the incoming call. Press and hold the Enter button to answer the incoming call and place the current call on hold.

#### 5.4.5 Mute

During a call, press and hold the Volume down button for 2 seconds to mute or un-mute the headset. There is a reminder tone every 10 seconds while the headset is muted.

#### 5.4.6 Re-dialing the last number

Double press the Enter button to redial the last called number on your phone.

## 6. Charging

When the battery is low, the EP620 beeps every 20 seconds and the status LED flashes red to indicate low power. To recharge the battery, use the supplied micro USB cable to connect the EP620 to a powered USB port.

The status LED constantly lights red whilst charging and turns blue once the battery is fully charged.

**Note:**

- 1) Only use certified USB chargers from branded manufacturers.
- 2) Fully charge the headset before first use.
- 3) If unused for a long period of time, fully charge the battery before use.

## 7. Specifications

Bluetooth Version	3.0 + EDR
Bluetooth Profile	HSP, HFP, A2DP
Operating Range	Up to 10m
Frequency Response	60Hz – 20KHz
Speaker Output	30mW
Battery	55mAh/3.7V Li-ion Polymer battery
Working Time	Up to 6 hours
Charging Time	About 1.5 hours
Charging Port	Micro USB
Weight	7g
Dimensions	5.9 x 1.3 x 0.75cm

## 8. Troubleshooting

### ■ The EP620 will not turn on.

- 1) Recharge the EP620. Refer to Section 6.
- 2) Press and hold the power button for 3 seconds.

### ■ The computer or mobile phone cannot find the EP620.

Confirm the EP620 is in pairing status and within 10 meters of the device.

### ■ The computer cannot install the driver for the EP620.

- 1) For Windows 98, XP and Vista computers, a third-party Bluetooth driver is needed (not included).
- 2) For Windows 7 and 8 computers, please update the driver of the Bluetooth module on your computer. For detailed information of your Bluetooth module, please contact the computer supplier.

### ■ The sound quality is intermittent in Bluetooth mode.

- 1) Please ensure the headset is within 10 metres of your source device.
- 2) Please disable the Wi-Fi on your source device.

### ■ There is no sound from the headset.

- 1) Check the volume on both the source device and the EP620.
- 2) If the headset is connected to a computer, please check that the headset is set as the current audio out device.

### ■ The mobile phone asks for a PIN code.

The PIN code for the EP620 is 0000.

## 9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.

- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

### Customer Service:

Telephone: +44 (0) 845 250 0586

Email: [service@augustint.com](mailto:service@augustint.com)