

# **August<sup>®</sup>**

## **User Manual**

**EP634**



**August International Ltd**

**United Kingdom**

**Telephone: +44 (0)845 250 0586**

**[www.augustint.com](http://www.augustint.com)**



**Bluetooth Wireless Stereo Headphones**

**Casque Stéréo Sans-fil Bluetooth**

**Kabellose Bluetooth Stereo Kopfhörer**

**Cuffie Stereo Senza Fili Bluetooth**

**Auriculares de Diadema Abiertos Bluetooth**

# User Manual

Thank you for purchasing the August EP634 Bluetooth Wireless Stereo Headphones. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

## Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble the EP634, it can be unsafe and will invalidate the manufacturer's warranty.

## Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

## Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: [service@augustint.com](mailto:service@augustint.com) should you require further technical support or customer service.







# Quick Start Guide

## EP634

1. Please fully charge the EP634 battery before first use by connecting the USB charging cable from a powered USB socket to the headphone power socket. Once fully charged, the red charging LED will turn off.
2. Switch the EP634 on by pressing and holding the power control on the top of the right earphone until the status LED starts to flash.
3. To pair, search for available Bluetooth devices on your mobile phone, tablet or computer. The headphones will appear as "EP634". Once paired, the status LED will slowly flash blue to confirm connection.
4. Playback is controlled by your source device, or via the on headphone controls for devices which support A2DP.
5. To connect to non Bluetooth device, use the 3.5mm cable to connect from the headphone socket of the source device to the 3.5mm socket of the EP634. Whilst connected via 3.5mm cable, the on headphone controls and microphone are disabled.



## 1. Safety Instructions

### ■ Storage and Use

	Do not store or use this device in extreme temperatures.		Do not store or use this device in wet or damp environments.
	Do not expose this device to dust, oil or smoke.		Do not drop or strike this device.
	When transporting this device store securely to avoid impact damage.		Do not scratch this device with sharp objects.

### ■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
--	--	---	--

## 2. Main Features

- Wireless Headphones for Bluetooth Devices
- Standard 3.5mm Audio-In Socket
- Hands-Free Calls with Integrated Microphone
- Built-in Rechargeable Battery
- Adjustable Headband
- Bluetooth Range: up to 10m (Class II)
- Bluetooth Version: v3.0+EDR

## 3. Accessories



Micro USB charging cable



3.5mm audio cable



User manual




## 4. Part Names and Functions






1. Power / Play / Pause / Answer
2. Volume Down / Previous Track
3. Power Socket
4. Audio-In Socket
5. Volume Up / Next Track
6. Microphone
7. Status LED

## 5. Operations

### 5.1 Switch On / Off

To switch on the device, press and hold the    button until the LED Flashes; a beep will be heard.

To switch off the device, press and hold the    button until the status LED stops flashing.

### 5.2 Bluetooth Connections

Turn the device on and wait for the status light to flash blue twice per second.

The device will automatically reconnect to the last paired Bluetooth device if in range. To connect to a new device, disable the Bluetooth of the known device prior to turning on the headphones.

#### - For mobile phones and tablets

1. Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed).
2. Select “EP634” from the available devices and confirm the connection. Some devices require a pin code. If this is the case, please enter the code “0000”.
3. Once successfully connected, the status LED flashes blue once every two seconds.

#### - For computers

1. Enable the Bluetooth function on your computer.
2. Select “Devices and Printers” from the Control Panel and click “Add a Device”.
3. Select “EP634” from the available devices, the system will install the driver automatically. If a pin code is requested, please enter the code “0000”.





**Note:** For Windows XP and Vista, a third-party Bluetooth driver is needed (not included).

4. Once successfully connected, the status LED flashes blue once every two seconds.
5. If the EP634 is not automatically set as your output device, select “Sound” from the Control Panel, then highlight the EP634 and select “Set as Default Device”.

### 5.3 Remote Control

The EP634 is able to control the music playing on a mobile phone, tablet, or computer that supports A2DP (refer to your devices user manual for its A2DP compatibility).

Press “   ” to pause or resume playing music.

Press and hold “  ” or “  ” to increase or decrease the volume.

Press “  ” or “  ” to select the previous or next track.

### 5.4 Hands-free Calling

Whilst connected to your mobile phone, the EP634 will act as a hands-free system for calls.

When there is an incoming call, press    to answer.

Press this button again to hang up.

Press and hold “  ” or “  ” to increase or decrease the volume.

### 5.5 Audio-In

To use the EP634 as a pair of wired headphones, use a 3.5mm audio cable to connect the EP634 to your source device. Once the audio cable is connected to the EP634, the device automatically switches to wired mode. The headphones do not need to be switched on for wired mode and the microphone and control buttons are disabled.

## 6. Charging

When the power is low, a warning sound is heard in the headphones.

To charge the EP634, connect the micro USB lead to the device's power socket, and the other end of the USB cable to a powered USB port.

The status LED lights red whilst charging, and goes out once fully charged.

## 7. Specification

Bluetooth Specification	V3.0 +EDR
Operating Range	Up to 10m
Frequency Response	20Hz-20KHz
Speaker Output	30mW
SNR	$\geq 70 \pm 3$ dB
Distortion	$\leq 1\%$ At 1KHz
Battery	3.7V/450mAh Built-in Li-Polyme Battery
Working Time	Approximately 16 Hours
Charging Time	Approximately 2 Hours
Standby Time	up to 360 Hours
Weight	160g
Dimensions	175mm x 135mm x 62mm

## 8. Trouble Shooting

Problem	Solution
Why won't the headphones turn on?	Please charge the EP634.
Why can't I find the EP634 on my device?	Confirm the EP634 is in pairing mode and within 10 meters of the device.
Why can't I install the driver for the EP634 on my computer?	Update the driver of the Bluetooth module on your computer.
Why is the sound quality intermittent in Bluetooth mode?	Disable the Wi-Fi on your source device.
I am getting no sound, why is that?	Check the volume on both the source device and the EP634.

## 9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

### **This warranty is subject to the following conditions:**

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main units, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

### **Customer Service:**

Telephone: +44 (0) 845 250 0586

Email: [service@augustint.com](mailto:service@augustint.com)

This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at August International Ltd, Unit 5 Swains Mill, Crane Mead, Ware SG12 9PY, England.



#### **Industry Canada Statement**

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.