

AUGUST[®] User Manual

EP735



August International Ltd
United Kingdom

Tel: +44 (0)845 250 0586

www.augustint.com

- EN** Active Noise Cancelling Bluetooth Headphones
- FR** Casque Bluetooth à Réduction de Bruit Active
- DE** Bluetooth Kopfhörer mit Aktiver Geräuschreduzierung
- IT** Cuffie Bluetooth con Cancellazione Attiva del Rumore
- ES** Auriculares Bluetooth Con Cancelación de Ruido Activa

User Manual

Thank you for purchasing the EP735 Active Noise Cancelling Bluetooth Headphones. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of yourself and others, please read the Safety Instructions before using this device. Please do not disassemble the EP735 as it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

Declaration of Conformity







The Declaration of Conformity can be found on our website at <http://augustint.com/en/declaration/>

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

1. Safety Instructions

■ Storage and Use

	Do not store or use this device in extreme temperatures.		Do not store or use this device in wet or damp environments.
	Do not expose this device to dust, oil or smoke.		Do not drop or strike this device.
	When transporting this device, store securely to avoid impact damage.		Do not scratch this device with sharp objects.

■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
---	--	--	--

■ Warning:

1. Listening to headphones or earphones at high volume for prolonged periods can cause damage to your hearing.
2. Please be considerate to others and listen at a low volume while in public.
3. If you are experiencing tinnitus, stop using headphones or listen only at a very low volume.

2. Main Features


- Wireless Headphones for Bluetooth Devices
- Active Background Noise Reduction
- Integrated Microphone for Hands-Free Calls
- aptX and Multipoint Technology to Connect to Two Devices
- Long-life Rechargeable Li-ion Battery

3. Box Contents

 EP735	 Power Cable	 3.5mm Audio Cable	 Airplane Headphone Socket Adaptor
 User Manual	 Carry Case		

4. Part Names and Functions

4.1 Device Layout



1. Power / Play / Pause / Answer
2. Status LED
3. Next Track / Volume Up
4. Previous Track / Volume Down
5. ANC (Active Noise Cancelling)
6. Charging Socket
7. 3.5mm Audio Jack
8. Microphone

4.2 Remote Control

Button	Operation	Function
>	Press	Next Track
>	Press and hold	Volume Up
<	Press	Previous Track
<	Press and hold	Volume Down
Power	Press	Play / Pause; Pick up / Hang up a call
Power	Press and hold	Power on; Power off; Reject an incoming call

4.3 Status LED Meaning

Indication	LED Status
Pairing / Reconnecting	Quickly Flashing Blue
Paired	Slowly Flashing Blue
Noise Cancelling On	Green
Charging	Red
Fully Charged	Off

5. Operation

Please fully charge the EP735 before first use or if left unused for a long period of time.

To charge, use the power cable to connect the headphones to a powered USB port.

The charging LED lights red whilst charging and turns off once the battery is fully charged.

5.1 Power

Please fully charge the EP735 before the first use or if left unused for a long period of time. To charge, use the power cable to connect the headphones to a powered USB port.

The status LED will light red while charging and will turn off once fully charged. Ensure that the output voltage from the USB port or the charger is 5V.

5.2 Turn On / Off

Press and hold the Power button for 3 seconds to switch on the EP735. The EP735 will enter reconnection mode and the status LED will flash blue.

Press and hold the Power button for 3 seconds to switch off the EP735.

If there is no Bluetooth connection, the EP735 will turn off automatically after 10 minutes.

5.3 Bluetooth Connection

When the EP735 is switched on, it will enter reconnection mode and connect automatically to any previously known device. If no previously connected devices are found, the EP735 will enter pairing mode after 3 seconds.

To connect to a different device, turn off the EP735 first, then press and hold the Power button for 15 seconds to enter pairing mode.

In pairing mode, the status LED will flash blue rapidly.

- For mobile phones and tablets

1. Scan for available Bluetooth devices on your mobile phone or tablet.
(Please consult the device's user manual for further instructions if necessary.)
2. Select 'EP735' from the available devices and confirm the connection. Some devices require a pin code. If this is the case, please enter the code '0000'.
3. Once successfully connected, the status LED will flash blue.

- For computers

1. Enable the Bluetooth function on your computer.
2. Select 'Device and Printers' from the Control Panel and click 'Add a Device'.
3. Select 'EP735' from the available devices. The computer will automatically install the driver. If a pin code is requested, please enter the code '0000'.
4. Once successfully connected, the status LED will flash blue.

5.4 Multipoint

Multipoint allows you to connect your EP735 headphones to two source devices at the same time.

- To create a multipoint connection:

1. Turn off the EP735 and all source devices.

2. Press and hold the Power button for 3 seconds to turn on the EP735 and put it into pairing mode. In pairing mode the status LED will quickly flash blue.
3. Pair the EP735 to the first source device.
4. Turn off the Bluetooth on the first source device.
5. Press < and > to enable Multipoint.
6. Pair the EP735 to the second source device.
7. Turn on the Bluetooth on the first source device. The EP735 will automatically reconnect to the first source device.

- To disable the Multipoint function on the EP735:

1. Turn off the Bluetooth on both source devices.
2. Press and hold < for 3 seconds to disable the Multipoint function.

5.5 Noise Cancelling

Press the ANC button to enable / disable the noise cancelling function. The status LED will light green while noise cancelling is enabled.

6. Charging

Connect the EP735 to a powered USB port using the provided USB charging cable. The charging LED lights red whilst charging and turns off once the battery is fully charged. A full charge takes approximately 3.5 hours depending on power input.

Note:

- 1) Ensure that the output voltage from the USB port or the charger is 5V. Charging voltage greater than 5V may damage the headphones.
- 2) Please fully charge the EP735 before first use or if left unused for a long period of time.
- 3) If you are using a smart USB charger, use the common USB port and ensure that the output voltage is 5V.

7. Specification

Bluetooth Version	v4.1 with aptX
Bluetooth Distance	10m
Transmission Frequency	2.40GHz-2.48GHz
Support Profile	HSP/HFP/A2DP/AVRCP
Speaker Diameter	Ø40mm
Impedance	32Ω
Sensitivity	105+/- 3dB
Speaker Output	20mW x 2
Frequency Response	20Hz-20kHz
Signal and Noise Ratio(SNR)	≥85dB
Distortion	≤1%
Noise Reduction Level	Up to 20dB (at 100–300Hz)
Battery Type	3.7V/370mAh Built-in Li-Polyme Battery
Bluetooth Working Time	18 Hours
Bluetooth ANC Working Time	10 Hours
Charging Time	3.5 Hours
Charging Port	Micro USB
Dimensions	195 × 140 × 76mm
Net Weight	160g

8. Troubleshooting

Problem	Solution
Won't turn on.	<ul style="list-style-type: none">• Please ensure that the EP735 is charged.
Can't find the EP735.	<ul style="list-style-type: none">• Confirm that the EP735 is in pairing mode and within 10 meters of the device.
Can't install the driver for EP735 on a computer.	<ul style="list-style-type: none">• Update the driver of the Bluetooth module on your computer.
The sound quality is intermittent in Bluetooth mode.	<ul style="list-style-type: none">• Disable the Wi-Fi on your source device.
No sound.	<ul style="list-style-type: none">• Check the volume on both the source device and the EP735.

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance with the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty covers only the main units and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufacturer disclaims any liability for incidental or consequential damages.
- Please consult one of our customer service advisers before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The Declaration of conformity may be consulted online at <http://www.augustint.com/en/declaration>.



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.